

Home


Mail

PrtScr

Num Lock



Bakker Elkhuzen



Esc

F1

F2

F3

F4

F5

F6

F7



F8



F9



F10



F11



F12



Insert

Delete

~

!

@

#

\$

%

^

&

7

*

(

)

*

-

+

BackSpace



1

2

3

4

5

€

6

7

8

9

0

-

=

Tab



Q

W

E

R

T

Y

U

4

I

5

O

6

P

-

{

}

[

]

|

\

Caps Lock

A

S

D

F

G

H

J

1

K

2

L

3

:

+

"

,

Enter



Shift



Z

X

C

V

B

N

M

0

<

,

>

.

?

/

/

Shift



Ctrl

Fn

Start

Alt

AltGr

Ctrl

Page Up

PgUp

Page Down

Home

PgDn

End